



3/4" PLYWOOD

- 1 - 3/8 x 2 1/2 CARRIAGE BOLT
- 1 - 3/8 x 2 CARRIAGE BOLT

WASHERS + WING NUTS

INSTALL PART B INTO NOTCH OF PART D (GLUE + SCREW)

PUT CARRIAGE BOLT THROUGH PART C + D 2 1/2"

PUT CARRIAGE BOLT THROUGH PART B + A USING HOLE IN "A" THAT BEST FITS YOUR LATHE.

ADJUST SO CENTER OF 2" HOLE IN "A" IS AT CENTER LINE OF LATHE BY SLIDING UP + DOWN IN SLOT OF "B".